




LINE

Universal GM / SYSTEM GEMINI 18 EVEREST



ATTENTION!!!
 System GEMINI 18 EVEREST
 is designed for use with a minimum
 of three door wings

COMPONENTS

Handle
 Universal GM C

anti-dust brushes
 (self-adhesive)
 6.7 mm x 9 mm

textile door stop
 (inserted)
 4.8 mm x 4 mm

#16 i #18

Length: 2.7 m

Top track Gemini Decor

76 mm

Length:
 1.7 m, 2.35 m, 3.0 m, 4.05 m, 6.0 m

Track Everest

Length: 3.0 m

Bottom track Elegant II (A)
 Covering strip Elegant II (B)

A B

Length:
 1.7 m, 2.35 m, 3.0 m, 4.05 m, 6.0 m

Angle section ZW

20 mm x 18 mm

Length:
 1.7 m, 2.35 m, 3.0 m

Guiding track
 Focus WPFc-Duo

Bottom track
 WD18V HI-TEC

Guiding track
 Everest WPEv-Duo
 left / right



LINE

Universal GM


SYSTEM

GEMINI 18 EVEREST



SEVROLL®

Dimensions of opening



L - length of track Everest





 $W_a > X$ $L_{min.} = \frac{2}{3}W$

X - length of angle section

 $L_{max.} = W$ W_a - width of the wing with angle section

door height	- h	$h = H - 42 \text{ mm}$	
board height	- hb	$hb = h - 2 \text{ mm}$	
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$	
board width	#12,#18 - wb	$wb = w - 7 \text{ mm}$	
angle section mini length	- la	$la = w - 62.4 \text{ mm}$	

number of doors	- N	3	4	visual design - 4 wings
total overlap	- Z	64 mm	96 mm	




mirror dimension

mirror height - $h_m = hb - 4 \text{ mm}$ mirror width - $w_m = wb - 4 \text{ mm}$ **ATTENTION:**


Board to mirror contact area should be free from dirt and grease before applying double-sided tape.

Broken line indicates recommended positioning of double-sided tape



Installation method for handle
an guiding carriage with # 18 mm board
(handle UNIVERSAL GM # 18 mm)



Installation method for handle and guiding
carriage with # 12 mm board and # 4 mm mirror
(handle UNIVERSAL GM # 16 mm)



Installation method for angle-section 20 mm x 18 mm

assembly adhesive
(this is necessary
when using mirror)**ATTENTION!**

Angle section must be fastened to board with a minimum of 3 screws ~ 3 x 25.

ATTENTION!

Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired size. Film removal will reveal quality issues (eg. scratches)